


1 Schema a Blocchi
Block Diagram



(1) RS485 o CAN Dipende dalla versione
(1) RS485 or CAN Depends from version

Per il pinning dei connettori vedere MNL160*100.
For connector pinning see MNL160*100

CE

SlimLine ARM9 CPU Block Diagram

MNL162A100



Via G. Brodolini, 15 (Z.I.) 15033 CASALE M.TO (AL) ITALY
Phone +39-0142-451987 Fax +39-0142-451988
Internet: <http://www.elgist.it> email: elgist@elgist.it